



VR00015 Vacuum Relief Valve Installation Instructions

Step 1:

Drill 2 ½" diameter hole with a hole-saw

Step 2:

Ensure that the hole is cut clean. Irregular holes could cause poor seating and possible leaks.

1.

Step 3:

Insert the Uni-seal with the wide surface facing out.

Step 4:

Use liquid soap or Teflon lube on the pipe end of the vacuum relief valve. Insert the pipe into the Uni-seal as far as the relief valve will go in. The lubricant will be squeezed off the pipe as it passes through the Uni-seal.